

YACHT  **SENTINEL**

User Manual

Sail through the YS Marina setup process



Contents

English

Congratulations on purchasing your YS Marina. This user manual will provide everything you need to know to get your router up and running. For more detailed information, please visit our website at www.yacht-sentinel.com.

| | | | |
|---------------------------|---|---------------------|----|
| Setup device | 3 | Test | 11 |
| Power ON | 4 | Safety instructions | 12 |
| Connect to Wi-Fi | 6 | Disclaimer | 13 |
| Extend your Wi-Fi network | 7 | | |

What's in the box?



YS Marina



Micro USB
cable



User manual



Power adapter




Antennas

What you need
Everything is provided
in the box

1. Setup device

Option 1

If you are going to be using a SIM card to provide Wi-Fi throughout your boat you will need to insert your sim card now. You can find the Micro Sim slot on the bottom of the router. Then attach the 'Antennas'.




Option 2

However, if you are using the marina Wi-Fi or have your own and want to extend your network flip to page '5' and begin by "Connecting to Wi-Fi" after you have attached your antennas.


What you need
Everything is provided
in the box

2. Power ON

Step 1



Now power ON your device, you will need to use the micro USB to Universal power adapter provided. You will know the device is ON once the 'Power indicator' Led lights up blue.




What you need
Everything is provided
in the box

3. Connecting to Wi-Fi

Step 1

Once your device is ON use your phone to check for available Wi-Fi networks, there should now be a Wi-Fi network labeled YS_Marina_XXXX. Connect to this network the password should be stuck on below.



Step 2

If you inserted a SIM card into your unit then you should now be up and running. You can skip to the 'Test' section of the guide on page '9'.

What you need
Everything is provided
in the box

4. Extend your Wi-Fi network

If you want to extend your current Wi-Fi network instead of using a SIM card, follow these steps.

Step 1

Open your browser and type in **192.168.10.1**, you will then be asked to enter the password. The password is **'admin'**.



Step 2

Now on the top left-hand corner you need to click on **Wizard** and then select **Bridge**.



Step 3

On the '**Repeater Settings**' page, you will need to connect to your current Wi-Fi network to establish a connection between the two devices. Click on '**Scan Band**' and select 2.4GHz, then click Scan. You should then see a list of active Wi-Fi networks around you. Select the one you want to bridge a connection between and enter the password.

Once this is complete click '**Next**'.



Bridge Settings

Scan Band: 2.4GHz


SSID: automatic

Password:

Prev Next

Step 4

Now create a new access point name and password.



2.4G Wireless

SSID: YS_Marina

Password: 12345678


Prev Next

Step 5

You should now be on the **'Wi-Fi 5.8G'**, ignore this page and click next.

Step 6

Finally, confirm the name of your new Wi-Fi network and click **'Finish'**. Your device will then restart, after the restart is complete your network should be up and running.



2.4G Wireless

| | |
|----------|--|
| SSID | <input type="text" value="YS_Marina"/> |
| Password | <input type="text" value="12345678"/> |

Prev **Next**

5. Test

Step 1

To test if your internet connection is up and running, connect to your Wi-Fi network as normal and visit www.yacht-sentinel.com. If you have followed the steps correctly the website should load without any issue, if you are still experiencing problems, visit our website and talk to us over live chat or check out our FAQ's page.

6. Safety instructions

Yacht Sentinel Limited and its affiliates are not liable for any damage whatsoever arising from the use of the YS Marina.

Inspect the YS Marina before use. Report any damaged or missing items to your supplier immediately

Do not modify any products or add attachments not approved by Yacht Sentinel Limited.

Do not submerge the YS Marina under water.

Do not spill any food or liquids on the YS Marina.

If your YS Marina or any of the sensors do not operate normally, immediately contact an authorized dealer or Yacht Sentinel Limited customer support.

Do not try to open the YS Marina, otherwise your warranty will be void.

Do not operate your YS Marina if any damage is visible or suspected.

7. Disclaimer

The use of the YS Marina is at the user's own risk. Please visit our website www.yacht-sentinel.com to review our Terms and Conditions.

All new goods supplied by Yacht Sentinel Limited and its licensed dealers have a 12-month warranty from the date the goods were delivered (unless otherwise stated). This warranty does not affect your statutory rights as a consumer. If your unit develops a defect within the 12-month warranty period, please contact us for warranty service.

Please note that the warranty does not cover you for any defects in the goods arising from abnormal wear and tear, wilful damage, accident, negligence by you or any third party, use otherwise than in accordance with its intended use. Failure to follow the manufacturer or suppliers' instructions, or any alteration or repair carried out without Yacht Sentinel Limited's prior written approval will void the warranty.





YACHT  **SENTINEL**